



# JX60 - JX70 - JX80 - JX90 - JX95 MODEL TRACTORS SERVICE MANUAL

SECTIONS	
<b>GENERAL</b> .....	<b>00</b>
<b>ENGINE</b> .....	<b>10</b>
<b>CLUTCH</b> .....	<b>18</b>
<b>GEARBOX</b> .....	<b>21</b>
<b>TRANSMISSION OF MOTION</b> .....	<b>23</b>
<b>FRONT MECHANICAL TRANSMISSION</b> .....	<b>25</b>
<b>REAR MECHANICAL TRANSMISSION</b> .....	<b>27</b>
<b>POWER TAKE-OFF</b> .....	<b>31</b>
<b>BRAKES</b> .....	<b>33</b>
<b>HYDRAULIC SYSTEMS</b> .....	<b>35</b>
<b>STEERING</b> .....	<b>41</b>
<b>AXLE AND WHEELS</b> .....	<b>44</b>
<b>AUXILIARY EQUIPMENT</b> .....	<b>50</b>
<b>ELECTRICAL SYSTEM</b> .....	<b>55</b>
<b>CAB</b> .....	<b>90</b>

S E R V I C E

## INTRODUCTION

- ◇ *This manual is divided into sections identified by two-figure numbers. Each section has independent page numbering.  
For ease of reference, these sections have the same numbers and names as the Repairs Rate Book sections.*
- ◇ *The different sections can easily be found by consulting the table of contents on the following pages.*
- ◇ *The document number of the manual and the edition/update dates are given at the bottom of each page.*
- ◇ *The information contained in this manual was current on the date printed on each section. As CASE IH constantly improves its product range, some information may be out of date subsequent to modifications implemented for technical or commercial reasons or to meet legal requirements in different countries.  
In the event of conflicting information, consult the CASE IH Sales and Service Departments.*

## IMPORTANT WARNINGS

- ◇ *All maintenance and repair work described in this manual must be performed exclusively by CASE IH service technicians in strict accordance with the instructions given and using any specific tools necessary.*
- ◇ *Anyone who performs the operations described herein without strictly following the instructions is personally responsible for resulting injury or damage to property.*
- ◇ *The Manufacturer and all organisations belonging to the Manufacturer's distribution network, including but not restricted to national, regional or local distributors, will accept no responsibility for personal injury or damage to property caused by abnormal function of parts and/or components not approved by the Manufacturer, including those used for maintenance and/or repair of the product manufactured or marketed by the Manufacturer.  
In any case, the product manufactured or marketed by the Manufacturer is covered by no guarantee of any kind against personal injury or damage to property caused by abnormal function of parts and/or components not approved by the Manufacturer.*

TEXT AND ILLUSTRATIONS ARE THE PROPERTY  
OF CNH ITALIA S.p.A.



No part of the text or illustrations  
may be reproduced

PRINTED IN ?????

**CNH ITALIA S.p.A. - Viale delle Nazioni, 55 - 41100 MODENA - Italy**  
Technical Support - Technical Information  
Print No. ?????? - ?? - ????



# Repair Manual - JX Series Tractors

---

## CONTENTS

### GENERAL

### SECTION 00

#### General Instructions and Health and Safety

#### Chapter 1

Section	Description	Page
00 000	General instructions .....	1
	Notes for spare parts .....	2
	Notes for equipment .....	2
	Safety rules .....	3
	Consumables .....	6

### ENGINE

### SECTION 10

#### Engine System

#### Chapter 1

Section	Description	Page
10 000	General specification .....	2
	Injection pump calibration data .....	5
	General specifications .....	16
	Tightening torques .....	24
	Tools .....	25
	Cross-sectional views .....	28
	Lubrication and cooling system diagrams .....	32
	Fault diagnosis .....	35
10 001 10	Engine <i>Removal-Installation</i> .....	39
10 001 54	Engine <i>Bench overhaul</i> .....	53
	Checks, measurements and repairs .....	78
10 406 10	Radiator <i>Removal-Installation</i> .....	102
10 102 70	Crankshaft front oil seal <i>removal installation</i> .....	106
10 402 10	Coolant pump <i>removal installation</i> .....	112
10 402 30	Cooling system thermostat .....	115
10 206 14	Bosch injection pump <i>removal installation</i> .....	118
	Bosch injection pump <i>timing</i> .....	121
	Bosch injection pump <i>air bleeding</i> .....	123
10 218 30	Injectors <i>removal installation</i> .....	124
10 106 12	Valve clearance adjustment .....	126

<b>10 402 28</b>	Coolant pump overhaul .....	129
<b>10 001 30</b>	Compression test .....	130

## CLUTCH

## SECTION 18

### Clutches

### Chapter 1

Section	Description	Page
<b>18 000</b>	General specifications .....	1
	Tightening torques .....	2
	Tools .....	3
	Cross-sectional views .....	4
	Clutch Troubleshooting .....	5
<b>18 110 10</b>	Removal - Installation .....	6
	Overhaul .....	14
	Minimum permissible dimensions after refacing .....	18
	Adjustments .....	19
<b>18 100 40</b>	Adjustment of the main and PTO clutch control linkage .....	21

## GEARBOX

## SECTION 21

### Mechanical Transmission (12x4)

### Chapter 1

Section	Description	Page
<b>21 000</b>	Main data .....	1
	Tightening torques .....	2
	Tools .....	3
	Section views .....	3&5
	Description and operation .....	8
	Fault diagnosis .....	8
<b>21 110</b>	Removal - Refitting .....	see sect 27

### Reverser (12x12)

### Chapter 2

Section	Description	Page
<b>21 000</b>	Main data .....	1
	Tightening torques .....	2
	Tools .....	3
	Section views .....	3
	Description and operation .....	5
	Fault diagnosis .....	5
<b>21 110</b>	Removal-Refitting .....	6

### Reverser and Creeper (20x12)

### Chapter 3

Section	Description	Page
<b>21 000</b>	Main data .....	1
	Tightening torques .....	2
	Tools .....	3
	Section views .....	4

	Description and operation .....	6
	Fault diagnosis .....	6
21 110	Removal-Refitting .....	7

## DRIVE LINES

## SECTION 23

### Drive Lines

### Chapter 1

Section	Description	Page
23 000	Main specification .....	1
	Torque settings and Tools .....	2
	Cross-Sectional views .....	3
23 101 26	Transmission shafts and guard (Disassembly - Assembly) .....	4
23 101 40	Drive gear housing (Removal - Installation) .....	5
23 101 42	Drive gear housing removed (Disassembly - Assembly) .....	7

## FRONT AXLE MECHANICAL TRANSMISSION

## SECTION 25

### Front Axle Mechanical Transmission

### Chapter 1

Section	Description	Page
25 000	Main data .....	1
	Tightening torques .....	4
	Tools .....	6
	Cross-sectional views .....	7
	Description and operation .....	9
25 100 30	Complete front axle. Removal - Installation .....	10
25 100 38	Front axle. Removal - Installation .....	14
25 108 46-47	Steering knuckle bearing pins. Replacement .....	24
	Stub axle adjustment .....	25
	Wheel hub bearing adjustment .....	27
	Bevel drive adjustment .....	29
25 102 24	Front axle differential. Overhaul .....	36
25 100 27	Front axle differential with LIM-SLIP. Overhaul .....	37
	Front axle differential with NO SPIN. Overhaul .....	39
44 511 80	Leading drive wheels toe-in check .....	42

## REAR AXLE AND TRANSMISSION

## SECTION 27

### Rear Axle And Transmission

### Chapter 1

Section	Description	Page
27 000	Main data .....	1
	Tightening torques .....	3
	Special tools .....	5
	Cross-sectional views .....	7
	Description and operation and troubleshooting .....	9

<b>21.118.10 - 12</b>	Transmission-gearbox casing Removal-Installation .....	10
<b>21.118.85</b>	Transmission-gearbox casing Disassembly-Overhaul .....	27
	Gearbox driven shaft end float adjustment .....	35
	Differential lock engagement sleeve adjustment .....	36
	Determining the bevel pinion positioning adjustment ring .....	37
	Adjusting the taper roller bearings for the bevel pinion shaft .....	39
	Adjusting the bearings and checking the backlash .....	40
	Differential pinion and side gear backlash adjustment .....	44

## POWER TAKE-OFF

## SECTION 31

### Mechanical Power Take - Off

### Chapter 1

Section	Description	Page
<b>31 000</b>	Main specification .....	1
	Tools .....	3
	Torque settings .....	4
	Sectional drawings .....	5
	Description and operation .....	9
	Troubleshooting .....	10
	Removal - Refitting .....	11
<b>31 101</b>	Bench overhaul .....	14

## BRAKING SYSTEM

## SECTION 33

### Braking System

### Chapter 1

Section	Description	Page
<b>33 000</b>	Main data .....	1
	Tightening torques .....	2
	Cross-sectional views .....	2
	Description & Operation .....	9
	Tools - Troubleshooting .....	10
<b>33.206</b>	Front brake assembly mod. JX60 and JX70 removal and refitting - overhauling on the bench .....	11
<b>33.202.60</b>	Service brake removal and refitting .....	14
<b>33.202.50</b>	Removal-Refitting of front brake pumps .....	19
<b>33.202.40</b>	Bleeding air from the front braking system .....	23
<b>33.120.08</b>	Adjusting service brake pedals travel .....	24
<b>33.110.08</b>	Parking brake travel adjustment .....	24

## HYDRAULIC SYSTEM

## SECTION 35

### Rear Mechanical Hydraulic Lift

### Chapter 1

Section	Description	Page
<b>35 000</b>	Main specification .....	1
	Tightening torques .....	3

	Tools .....	6
	Cross-sectional views .....	7
	Description & Operation .....	9
	Hydraulic circuit .....	9
	Description and operation of lift phases .....	10
	Fault diagnosis .....	13
<b>35 110.30</b>	Hydraulic lift - disassembly reassembly .....	15
<b>35.110.40-42-46</b>	Hydraulic lift - bench overhaul .....	21
	Adjusting the lift .....	26
<b>35.110.08</b>	Linkage adjustment .....	32
<b>35.110.30</b>	Pressure relief valve - disassembly reassembly .....	34
<b>35.110.32</b>	Pressure relief valve - setting .....	34
<b>35.110.14</b>	Lift control valve - disassembly assembly and overhaul on bench .....	36
<b>35.0101.10</b>	Lift pump .....	41

## Open Centre System Auxiliary Control Valves

## Chapter 2

Section	Description	Page
<b>35 000</b>	Main data - Tools .....	1
	Auxiliary control valves - sectional views .....	2
	Description and operation .....	3
	Fault diagnosis .....	see chapter 1
<b>35 204 46</b>	Auxiliary control valves - Assembly-Disassembly .....	7
	Spool binding test .....	15
	Spool leakage test .....	16
	Adjustment of the automatic detent release pressure .....	17

## Trailer Brake Auxiliary Control Valve

## Chapter 3

Section	Description	Page
<b>35 000</b>	Section views .....	1
	Description and operation .....	1
	Hydraulic diagram .....	2
	Description and operation of valve phases .....	3
	Trailer brake auxiliary control valve linkage adjustment .....	6

## STEERING

## SECTION 41

### Steering

### Chapter 1

Section	Description	Page
<b>41 000</b>	Principal data .....	1
	Tightening torques .....	3
	Section views .....	4
	Hydraulic diagram .....	6
	Operation .....	7
	Fault diagnosis .....	9
	Tools .....	10
<b>41 204 30</b>	Hydrostatic steering control valve - Removal-Installation .....	11
<b>41 204 34</b>	Hydrostatic steering control valve - Disassembly-Assembly .....	14
<b>41 204 38</b>	Hydrostatic steering control valve - Bench testing .....	28
	Hydrostatic steering oil pump - Disassembly-Assembly .....	30
<b>41 216 20</b>	Steering cylinder (two-wheel drive axle) - Removal-Refitting .....	32
	Steering cylinder (four wheel drive axle) - Removal-Refitting .....	33

## FRONT AXLE AND WHEELS

## SECTION 44

## Front Axle And Wheels

## Chapter 1

Section	Description	Page
44 000	Principal data .....	1
	Sectional views .....	3
	Torque settings .....	4
	Equipment - Fault diagnosis .....	5
	Removal-Refitting-Overhaul .....	6
44 101 30	Wheel hub disassembly-assembly .....	9
44 101 22	Stub axle overhaul .....	16
44 101 46	Checking wheel alignment .....	20

## AUXILIARY UNITS

## SECTION 50

### Auxiliary Units

### Chapter 1

Section	Description	Page
50 000	Safety instructions .....	2
	General characteristics .....	3
	Equipment .....	4
	Operating principles .....	5
	Fault diagnosis .....	7
	Cab controls .....	11
	Use .....	14
	Main components of the cab air conditioning system .....	15
	Refrigerant recovery-recycling and evacuation-charging stations .....	20
	Drying recharging and checking cooling .....	22
50 200 04	Functional testing of air conditioning system .....	27
	Summary of the cab air-conditioning system charging operations .....	28
	Checking for refrigerant leaks using an electronic leak detector .....	30
	Summary of fault diagnosis and maintenance .....	31
	Air conditioning and heating pipes - Replacement .....	33
50 200 04-74	Receiver-drier - Replacement .....	36
50 200 04-72	Condenser - Replacement .....	38
50 200 04-26	Compressor - Removal-Refitting .....	39
50 200 10	Compressor drive belt tension adjustment .....	41

## ELECTRICAL SYSTEM

## SECTION 55

### Instruments

### Chapter 1

Section	Description .....	Page
	Analogue instruments Introduction .....	1
	Transmitter and switch .....	4



## Components

## Chapter 2

Section	Description	Page
55 500	Introduction	1
	Component description	1

## Starting System

## Chapter 3

Section	Description	Page
55 000	Technical information	1
	Tightening torques	1
	Description and operation	2
	Starting circuit	3
	System tests	5
55 201	Removal and re-installation of starter motor	8
	Servicing	9
	Bench tests	10

## Charging System

## Chapter 4

Section	Description	Page
55 000	Technical information	1
	Tightening torques	1
	Description and operation	2
	System testing and trouble-shooting	4
55 301	Removal, re-installation and servicing	10

## Battery

## Chapter 5

Section	Description	Page
55 000	Technical information	1
	Description and operation	1
55.301.040	Removal and re-installation	2
	Battery checking and maintenance	3
	Charging the battery	4
	Battery problems - Frequent causes	7

## Electrical Circuits

## Chapter 6

Section	Description	Page
55 100	Contents	1
	Fuses (all versions)	2
	Symbols used in electrical circuits	4
	Electrical wire colour coding	5
	Ground locations	5
	Electrical diagrams	
	- General diagrams (W/Cab)	9

- General diagrams (W/Out Cab) .....	15
- Analogue instrument circuit and connector overview .....	19
- Start-up circuit and connector overview .....	21
- Direction indicator & hazard warning light circuit and connector overview ....	25
- Windscreen and rear window wiper/washer circuit and connector overview ...	31
- Brake light circuit and connector overview .....	35
- Heating and air-conditioning system circuit and connector overview .....	41
- Work lamp (without cab circuit and connector overview) .....	45
- Work lamp (without cab circuit and connector overview) .....	49
- Side lights,main and dipped headlights, parking light circuit and connector overview	53

## BODYWORK AND DRIVER POSITION

## SECTION 90

### Bodywork And Driver Position

### Chapter 1

Section	Description .....	Page
<b>90 160 42 - 43</b>		
<b>90 120 10</b>	Control levers, seat and electrical controls - disassembly and reassembly .....	2
<b>90 156 52</b>	Rear window, handle and lock - disassembly and reassembly .....	10
<b>90 154 30</b>	Left-hand door exterior handle and lock - disassembly and reassembly .....	11
<b>90 154 10</b>	Left-hand door - disassembly and reassembly .....	12
<b>90 160 60</b>		
<b>55 518 52</b>	Windscreen wiper motor - disassembly and reassembly .....	13
<b>90154 24</b>		
<b>90 156 10 - 14</b>		
<b>90 156 28</b>	Cab windows - replacement .....	15

## GENERAL INSTRUCTIONS

### IMPORTANT NOTICE

All maintenance and repair operations described in this manual should be carried out exclusively by the CASE IH authorised workshops. All instructions detailed should be carefully observed and special equipment indicated should be used if necessary.

Everyone who carries out service operations described without carefully observing these prescriptions will be directly responsible of deriving damages.

### SHIMMING

At each adjustment, select adjusting shims, measure them individually using a micrometer and then sum up recorded values. Do not rely on measuring the whole shimming set, which may be incorrect, or on rated value indicated for each shim.

### ROTATING SHAFT SEALS

To correctly install rotating shaft seals, observe the following instructions:

- Let the seal soak into the same oil as it will seal for at least half an hour before mounting;
- Thoroughly clean the shaft and ensure that the shaft working surface is not damaged;
- Place the sealing lip towards the fluid. In case of a hydrodynamic lip, consider the shaft rotation direction and orient grooves in order that they deviate the fluid towards the inner side of the seal;
- Coat the sealing lip with a thin layer of lubricant (oil rather than grease) and fill with grease the gap between the sealing lip and the dust lip of double lip seals;
- Insert the seal into its seat and press it down using a flat punch. Do not tap the seal with a hammer or a drift;
- Take care to insert the seal perpendicularly to its seat while you are pressing it. Once the seal is settled, ensure that it contacts the thrust element if required.;
- To prevent damaging the sealing lip against the shaft, place a suitable protection during installation.

### O RINGS

Lubricate the O rings before inserting them into their seats. This will prevent the O rings from rolling over and twine during mounting which will jeopardise sealing.

### SEALERS

Apply one of the following sealers: RTV SILMATE, RHODORSIL CAF 1, or LOCTITE PLASTIC GASKET over the mating surfaces marked with an X.

Before applying the sealer, prepare the surface as follows:

- remove possible scales using a metal brush;
- thoroughly degrease the surfaces using one of the following cleaning agent: trichlorethylene, petrol or a water and soda solution.

### BEARINGS

It is advisable to heat the bearings to 80 to 90°C before mounting them on their shafts and cool them down before inserting them into their seats with external tapping.

### ROLL PINS

When fitting straight roll pins, ensure that the pin notch is oriented in the direction of the effort to stress the pin. Coil roll pins can be installed in any position.

**NOTES FOR SPARE PARTS**

Use exclusively **genuine CASE IH spare parts**, the only ones bearing this logo.



Only genuine parts guarantee same quality, life, safety as original components as they are the same as mounted in production.

Only the **CASE IH genuine spare parts** can offer this guarantee.

All spare parts orders should be complete with the following data:

- tractor model (commercial name) and frame number;
- engine type and number;
- part number of the ordered part, which can be found on the “Microfiches” or the “Spare Parts Catalogue”, which is the base for order processing.

**NOTES FOR EQUIPMENT**

Equipment which CASE IH proposes and shows in this manual are as follows:

- studied and designed expressly for use on CASE IH tractors;
- necessary to make a reliable repair;
- accurately built and strictly tested to offer efficient and long-lasting working means.

We also remind the Repair Personnel that having these equipment means:

- work in optimal technical conditions;
- obtain best results;
- save time and effort;
- work more safely.

**NOTICES**

Wear limits indicated for some details should be intended as advised, but not binding values. The words “front”, “rear”, “right hand”, and “left hand” referred to the different parts should be intended as seen from the operator’s seat oriented to the normal sense of movement of the tractor.

**HOW TO MOVE THE TRACTOR WITH THE BATTERY REMOVED**

Cables from the external power supply should be connected exclusively to the respective terminals of the tractor positive and negative cables using pliers in good condition which allow proper and steady contact.

Disconnect all services (lights, wind-shield wipers, etc.) before starting the tractor.

If it is necessary to check the tractor electrical system, check it only with the power supply connected. At check end, disconnect all services and switch the power supply off before disconnecting the cables.

## SAFETY RULES

### PAY ATTENTION TO THIS SYMBOL



*This warning symbol points out important messages involving personal safety. Carefully read the safety rules contained herein and follow advised precautions to avoid potential hazards and safeguard your safety and personal integrity.*

*In this manual you will find this symbol together with the following key-words:*

**WARNING** – *it gives warning about improper repair operations and deriving potential consequences affecting the service technician's personal safety.*

**DANGER** – *it gives specific warning about potential dangers for personal safety of the operator or other persons directly or indirectly involved.*



## TO PREVENT ACCIDENTS

Most accidents and personal injuries taking place in workshops are due from non-observance of some simple and essential prudential rule and safety precautions. For this reason, **IN MOST CASES THEY CAN BE AVOIDED.** It suffices to foresee possible causes and act consequently with necessary caution and care.

The possibility that an accident might occur with any type of machines should not be disregarded, no matter how well the machine in question was designed and built.

A wise and careful service technician is the best precautions against accidents.

Careful observance of this only basic precaution would be enough to avoid many severe accidents.

**DANGER:** Never carry out any cleaning, lubrication or maintenance operations when the engine is running.

## SAFETY RULES

### GENERALITIES

- ◇ Carefully follow specified repair and maintenance procedures.
- ◇ Do not wear rings, wristwatches, jewels, unbuttoned or flapping clothing such as ties, torn clothes, scarves, open jackets or shirts with open zips which could get hold into moving parts. We advise to use approved safety clothing such as anti-slipping footwear, gloves, safety goggles, helmets, etc.
- ◇ Never carry out any repair on the machine if someone is sitting on the operator's seat, except if they are certified operators to assist in the operation to be carried out.
- ◇ Never operate the machine or use attachments from a place other than sitting at the operator's seat.
- ◇ Never carry out any operation on the machine when the engine is running, except when specifically indicated.
- ◇ Stop the engine and ensure that all pressure is relieved from hydraulic circuits before removing caps, covers, valves, etc.
- ◇ All repair and maintenance operations should be carried out with the greatest care and attention.
- ◇ Service stairs and platforms used in a workshop or in the field should be built in compliance with the safety rules in force.
- ◇ Disconnect the batteries and label all controls to warn that the tractor is being serviced. Block the machine and all equipment which should be raised.
- ◇ Never check or fill fuel tanks and accumulator batteries, nor use starting liquid if you are smoking or near open flames as such fluids are flammable.
- ◇ Brakes are inoperative when they are manually released for maintenance purposes. In such cases, the machine should be kept constantly under control using blocks or similar devices.
- ◇ The fuel filling gun should remain always in contact with the filler neck. Maintain this contact until the fuel stops flowing into the tank to avoid possible sparks due to static electricity buildup.

- ◇ Use exclusively specified towing points for towing the tractor. Connect parts carefully. Ensure that foreseen pins and/or locks are steadily fixed before applying traction. Do not stop near towing bars, cables or chains working under load.
- ◇ To transfer a failed tractor, use a trailer or a low loading platform trolley if available.
- ◇ To load and unload the machine from the transportation mean, select a flat area providing a firm support to the trailer or truck wheels. Firmly tie the machine to the truck or trailer platform and block wheels as required by the forwarder.
- ◇ For electrical heaters, battery–chargers and similar equipment use exclusive auxiliary power supplies with a efficient ground to avoid electrical shock hazard.
- ◇ Always use lifting equipment and similar of appropriate capacity to lift or move heavy components.
- ◇ Pay special attention to bystanders.
- ◇ Never pour gasoline or diesel oil into open, wide and low containers.
- ◇ Never use gasoline, diesel oil or other flammable liquids as cleaning agents. Use non–flammable non–toxic proprietary solvents.
- ◇ Wear protection goggles with side guards when cleaning parts using compressed air.
- ◇ Do not exceed a pressure of 2.1 bar, in accordance with local regulations.
- ◇ Do not run the engine in a closed building without proper ventilation.
- ◇ Do not smoke, use open flames, cause sparks in the nearby area when filling fuel or handling highly flammable liquids.
- ◇ Do not use flames as light sources when working on a machine or checking for leaks.
- ◇ Move with caution when working under a tractor, and also on or near a tractor. Wear proper safety accessories: helmets, goggles and special footwear.
- ◇ During checks which should be carried out with the engine running, ask an assistant to seat at the operator’s seat and keep the service technician under visual control at any moment.
- ◇ In case of operations outside the workshop, drive the tractor to a flat area and block it. If working on an incline cannot be avoided, first block the tractor carefully. Move it to a flat area as soon as possible with a certain extent of safety.
- ◇ Ruined or plied cables and chains are unreliable. Do not use them for lifting or trailing. Always handle them wearing gloves of proper thickness.
- ◇ Chains should always be safely fastened. Ensure that fastening device is strong enough to hold the load foreseen. No persons should stop near the fastening point, trailing chains or cables.
- ◇ The working area should be always kept CLEAN and DRY. Immediately clean any spillage of water or oil.
- ◇ Do not pile up grease or oil soaked rags, as they constitute a great fire hazard. Always place them into a metal container.  
Before starting the tractor or its attachments, check, adjust and block the operator’s seat. Also ensure that there are no persons within the tractor or attachment operating range.
- ◇ Do not keep into your pockets any object which might fall unobserved into the tractor’s inner compartments.
- ◇ Whenever there is the possibility of being reached by ejected metal parts or similar, use protection eye mask or goggles with side guards, helmets, special footwear and heavy gloves.
- ◇ Wear suitable protection such as tinted eye protection, helmets, special clothing, gloves and footwear whenever it is necessary to carry out welding procedures. All persons standing in the vicinity of the welding process should wear tinted eye protection. NEVER LOOK AT THE WELDING ARC IF YOUR EYES ARE NOT SUITABLY PROTECTED.
- ◇ Metal cables with the use get frayed. Always wear adequate protections (heavy gloves, eye protection, etc.)
- ◇ Handle all parts with the greatest caution. Keep your hands and fingers far from gaps, moving gears and similar. Always use approved protective equipment, such as eye protection, heavy gloves and protective footwear.

**START UP**

- ◇ Never run the engine in confined spaces which are not equipped with adequate ventilation for exhaust gas extraction.
- ◇ Never bring your head, body, arms, legs, feet, hands, fingers near fans or rotating belts.

**ENGINE**

- ◇ Always loosen the radiator cap very slowly before removing it to allow pressure in the system to dissipate. Coolant should be topped up only when the engine is stopped or idle if hot.
- ◇ Do not fill up fuel tank when the engine is running, mainly if it is hot, to avoid ignition of fires in case of fuel spilling.
- ◇ Never check or adjust the fan belt tension when the engine is running. Never adjust the fuel injection pump when the tractor is moving.
- ◇ Never lubricate the tractor when the engine is running.

**ELECTRICAL SYSTEMS**

- ◇ If it is necessary to use auxiliary batteries, cables must be connected at both sides as follows: (+) to (+) and (–) to (–). Avoid short-circuiting the terminals. **GAS RELEASED FROM BATTERIES IS HIGHLY FLAMMABLE.** During charging, leave the battery compartment uncovered to improve ventilation. Avoid checking the battery charge by means of “jumpers” made by placing metallic objects across the terminals. Avoid sparks or flames near the battery area. Do not smoke to prevent explosion hazards.
- ◇ Prior to any service, check for fuel or current leaks. Remove these leaks before going on with the work.
- ◇ Do not charge batteries in confined spaces. Ensure that ventilation is appropriate to prevent accidental explosion hazard due to build-up of gases released during charging.
- ◇ Always disconnect the batteries before performing any type of service on the electrical system.

**HYDRAULIC SYSTEMS**

- ◇ Some fluid slowly coming out from a very small port can be almost invisible and be strong enough to penetrate the skin. For this reason, **NEVER USE YOUR HANDS TO CHECK FOR LEAKS**, but use a piece of cardboard or a piece of wood to this purpose. If any fluid is injected into the skin, seek medical aid immediately. Lack of immediate medical attention, serious infections or dermatosis may result.
- ◇ Always take system pressure readings using the appropriate gauges.

**WHEELS AND TYRES**

- ◇ Check that the tyres are correctly inflated at the pressure specified by the manufacturer. Periodically check possible damages to the rims and tyres.
- ◇ Keep off and stay at the tyre side when correcting the inflation pressure.
- ◇ Check the pressure only when the tractor is unloaded and tyres are cold to avoid wrong readings due to over-pressure. Do not reuse parts of recovered wheels as improper welding, brazing or heating may weaken the wheel and make it fail.
- ◇ Never cut, nor weld a rim with the inflated tyre assembled.
- ◇ To remove the wheels, block both front and rear tractor wheels. Raise the tractor and install safe and stable supports under the tractor in accordance with regulations in force.
- ◇ Deflate the tyre before removing any object caught into the tyre tread.
- ◇ Never inflate tyres using flammable gases as they may originate explosions and cause injuries to bystanders.

**REMOVAL AND INSTALLATION**

- ◇ Lift and handle all heavy components using lifting equipment of adequate capacity. Ensure that parts are supported by appropriate slings and hooks. Use lifting eyes provided to this purpose. Take care of the persons near the loads to be lifted.
- ◇ Handle all parts with great care. Do not place your hands or fingers between two parts. Wear approved protective clothing such as safety goggles, gloves and footwear.
- ◇ Do not twine chains or metal cables. Always wear protection gloves to handle cables or chains.

**CONSUMABLES**

COMPONENT TO BE FILLED OR TOPPED UP	QUANTITY			CASE IH RECOMMENDED PRODUCTS	INTERNATIONAL SPECIFICATION
	litres/dm <sup>3</sup>	US gal	IMP gal		
Cooling system: JX60, JX70 models JX80, JX90, JX95 models with cab : JX60, JX70 models JX80, JX90, JX95 models	12 14 14 16	3.2 3.7 3.7 4.2	2.64 3.08 3.1 3.5	Water & liquid <b>AKCELA PREMIUM ANTI-FREEZE</b> <b>50% + 50%</b>	–
Windscreen washer bottle .....	2	0.53	0.44	Water & cleaning liquid	–
Fuel tank	90	23.8	19.8	Decanted and filtered diesel fuel	–
Additional fuel tank (Optional) .....	27	7.1	5.94		–
Engine sump: without filter : JX60, JX70 models JX80, JX90, JX95 models with filter : JX60, JX70 models JX80, JX90, JX95 models	7.6 10.5 8.3 11.2	1.98 2.77 2.19 2.96	1.67 2.31 1.83 2.46	<b>AKCELA No.1 ENGINE OIL</b>  <b>API CH-4 * ACEA E5 * MB 228.3 * CUMMINS CES 200072/20076/20077</b>	API CF-4/SG CCMC D4 MIL-L-2104E
Brake control circuit .....	0.4	0.1	0.09	<b>AKCELA LHM FLUID Oil</b>	ISO 7308
Hydrostatic steering circuit .....	2.0	0.5	0.44	Oil <b>AKCELA NEXPLORE</b>	API GL4 ISO 32/46 SAE 10W-30
Front axle: – axle housing : JX60, JX70 models JX80, JX90, JX95 models – final drives (each) : JX60, JX70 HP models JX80, JX90, JX95 models	4.5 7.0 0.8 1.25	1.2 1.8 0.2 0.3	0.99 1.54 0.18 0.28		
Rear transmission (bevel drive and brakes), gearbox, hydraulic lift and PTO JX60, JX70, JX80, JX90, JX95 models .....	46	12.15	10.12		
– with synchro-reverser: JX60, JX70, JX80, JX90, JX95 models .....	46	12.15	10.12		
Rear final drives (each) : JX60, JX70 HP models JX80, JX90, JX95 models	3.9 5.3	1.03 1.40	0.86 1.17		
Front wheel hubs .....	–	–	–		
Grease fittings .....	–	–	–		



## SECTION 10 - ENGINE

## Chapter 1 - Engine

## CONTENTS

Section	Description	Page
<b>10 000</b>	General specification .....	2
	Injection pump calibration data .....	5
	General specifications .....	16
	Tightening torques .....	24
	Tools .....	25
	Cross-sectional views .....	28
	Lubrication and cooling system diagrams .....	32
	Fault diagnosis .....	35
<b>10 001 10</b>	Engine <i>Removal-Installation</i> .....	39
<b>10 001 54</b>	Engine <i>Bench overhaul</i> .....	53
	Checks, measurements and repairs .....	78
<b>10 406 10</b>	Radiator <i>Removal-Installation</i> .....	102
<b>10 102 70</b>	Crankshaft front oil seal <i>removal installation</i> .....	106
<b>10 402 10</b>	Coolant pump <i>removal installation</i> .....	112
<b>10 402 30</b>	Cooling system thermostat .....	115
<b>10 206 14</b>	Bosch injection pump <i>removal installation</i> .....	118
	Bosch injection pump <i>timing</i> .....	121
	Bosch injection pump <i>air bleeding</i> .....	123
<b>10 218 30</b>	Injectors <i>removal installation</i> .....	124
<b>10 106 12</b>	Valve clearance adjustment .....	126
<b>10 402 28</b>	Coolant pump overhaul .....	129
<b>10 001 30</b>	Compression test .....	130

GENERAL SPECIFICATIONS	3 cylinders	4 cylinders
<b>Engine type:</b>		
- mod. JX60 normally aspirated - type 8035.05D.939 (BOSCH pump) .....	see data pages 6-7	-
- mod. JX70 turbocharged - type 8035.25C.939 (BOSCH pump) .....	see data pages 8-9	-
- mod. JX80 normally aspirated - type 8045.05R.939 (BOSCH pump) .....	-	see data pages 10-11
- mod. JX90 turbocharged - type 8045.25.939 (BOSCH pump) .....	-	see data pages 12-13
- mod. JX95 turbocharged - type 8045.25L.939 (BOSCH pump) .....	-	see data pages 14-15
Cycle .....	Diesel, 4-stroke	
Fuel injection .....	Direct	
Number of cylinders in line .....	3	4
Cylinder liners .....		dry force-fitted in cylinder block
Piston diameter		
- mod. JX60 .....	104 mm (4.0945 in.)	-
- mod. JX70 .....	104 mm (4.0945 in.)	-
- mod. JX80 .....	-	104 mm (4.0945 in.)
- mod. JX90 .....	-	104 mm (4.0945 in.)
- mod. JX95 .....	-	104 mm (4.0945 in.)
Piston stroke .....	115 mm (4.5276 in.)	
Total displacement:		
- mod. JX60-JX70 .....	2931 cm <sup>3</sup> (178.8496 in. <sup>3</sup> )	-
- mod. JX80-JX90-JX95 .....	-	3908 cm <sup>3</sup> (238.4662 in. <sup>3</sup> )
Compression ratio .....	17 to 1 normally aspirated 16.5 to 1 turbocharged	
Maximum power 2000/25 EC at 2500 rpm:		
- mod. JX60 .....	43.4 kW (59 hp)	-
- mod. JX70 .....	50.7 kW (69 hp)	-
- mod. JX80 .....	-	58.8 kW (80 hp)
- mod. JX90 .....	-	65.5 kW (89 hp)
- mod. JX95 .....	-	69.1 kW (94 hp)
Maximum power ECE R 24 at 2500 rpm:		
- mod. JX60 .....	41.2 kW (56 hp)	-
- mod. JX70 .....	47.8 kW (65 hp)	-
- mod. JX80 .....	-	55.9 kW (76 hp)
- mod. JX90 .....	-	63.3 kW (86 hp)
- mod. JX95 .....	-	66.9 kW (91 hp)
Fast idling speed .....	2500 rpm.	
Maximum torque (daNm) at 1500 rpm: JX60 model .....	20.7 (152.6753 ft lb)	-
Maximum torque (daNm) at 1500 rpm: JX70 model .....	25.0 (184.3905 ft lb)	-
Maximum torque (daNm) at 1500 rpm: JX80 model .....	-	27.9 (205.9778 ft lb)
Maximum torque (daNm) at 1500 rpm: JX90 model .....	-	32.0 (236.0194 ft lb)
Maximum torque (daNm) at 1500 rpm: JX95 model .....	-	33.7 (248.5584 ft lb)
Number of main bearings .....	4	5
Sump .....	Structural, cast iron	

(continued)

GENERAL SPECIFICATIONS	3 cylinders	4 cylinders
<b>Lubrication</b> ..... Pump drive ..... Engine speed/oil pump speed ratio ..... Oil cleaning ..... Normal oil pressure, with engine hot and at fast idling speed . Pressure relief valve ..... Valve opening pressure ..... For further lubrication data .....	forced, with gear pump camshaft 2:1 mesh filter on oil intake and cartridge filter on delivery line 2.9 to 3.9 bar (42.06 to 56.56 psi) built into pump housing 3.5 bar (50.76 psi) See page 23	
<b>Cooling system</b> ..... Radiator on JX60, JX70, JX80 and JX90 models ..... Radiator on JX95 models ..... Fan, attached to coolant pump pulley ..... Coolant pump ..... Engine speed/coolant pump speed ratio ..... Temperature control ..... Coolant temperature gauge ..... Temperature ranges corresponding to each section: - initial white section ..... - middle green section ..... - final red section ..... For further cooling system data .....	coolant circulation three-row vertical pipes with copper fins four-row vertical pipes with copper fins four-blade steel exhauster fan 6-blade steel exhauster fan (JX95) centrifugal vane-type 1:1,403 Thermostat coloured scale divided into three sections from 30° to 65° C (86° to 149° F) from 65° to 105° C (149° to 221° F) from 105° to 115° C (221° to 300.2° F) See page 23	
<b>Rev counter</b> ..... Rev counter drive ..... Hour counter calibrated for engine speed of .....	incorporated in control panel from gear on camshaft 1800 rpm.	

(Continued)

(continued)

GENERAL SPECIFICATIONS	3 cylinders	4 cylinders
<b>Timing</b> ..... Intake: - start: before T.D.C ..... - end: after B.D.C ..... Exhaust: - start: before B.D.C ..... - end: after T.D.C ..... Valve clearance for timing check ..... Valve clearance for normal running (engine cold): - intake ..... - exhaust ..... For further timing data .....	overhead valves operated by a camshaft located in the engine block through tappets, pushrods and rockers. Camshaft is driven by the crankshaft through helical gears.  12° 31°  50° 16°  0.45 mm (0.0177 in.)  0.30 ± 0.05 mm (0.0118 ± 0.0020 in.) 0.30 ± 0.05 mm (0.0118 ± 0.0020 in.)  See page 20	
<b>Fuel System</b> Air cleaning ..... Fuel pump ..... Fuel filter ..... Minimum fuel flow rate with pump shaft rotating at 1600 rev/min. Operated by eccentric cam ..... BOSCH Injection pump ..... All-speed governor, incorporated in pump: BOSCH Automatic advance regulator, incorporated in pump: BOSCH For further fuel system data:  For fixed advance (pump setting for start of delivery before TDC) - Pressure setting - Injection order, and other information regarding the BOSCH pump	dual cartridge dry air filter, with clogged filter indicator with centrifugal pre-filter and automatic dust ejector. with double diaphragm  mesh filter in fuel supply pump, and replaceable cartridge on delivery line to injection pump. 100 litres/hour  on camshaft  rotary distributor type  centrifugal counterweights  hydraulic  see pages 5 to 15  refer to the data for the relevant engine type in the tables from page 6 to page 14.	

## DATA

Turbocharger (Model JX95): - ..... GARRETT type .....		T25			
Fuel injection pump ..... BOSCH pump: - ..... JX60 model ..... - ..... JX70 model ..... - ..... JX80 model ..... - ..... JX90 model ..... - ..... JX95 model ..... Direction of rotation ..... Injection order .....		distributor type with incorporated speed governor and automatic advance regulator  VE 3/12 F 1250 L 976 - 504054473 VE 3/12 F 1250 L 977 - 504054474 VE 4/12 F 1250 L 985 - 504041416 VE 4/12 F 1250 L 982 - 504042214 VE 4/12 F 1250 L 952 - 504042718  anticlockwise  1-2-3 (JX60 and JX70) 1-3-4-2 (JX80, JX90 and JX95)			
Fuel injectors: BOSCH ..... - Nozzle holder type ..... - Nozzle type ..... Number of nozzle holes ..... Diameter of nozzle orifices ..... Pressure setting .....	5  248-272 bar (3596.9176-3945.0064 psi)	6  248-272 bar (3596.9176-3945.0064 psi)			
	JX70	JX95	JX60	JX80	JX90
Fuel delivery lines - BOSCH pump - Type ..... - Dimensions ..... mm	-	-	-	-	-

## JX60 MODEL - CALIBRATION DATA FOR BOSCH INJECTION PUMP TYPE VE 3/12 F 1250 L 976 - 504054473

### ASSEMBLY DATA

Pump timing on engine: delivery start  $4^\circ \pm 0.5^\circ$  before TDC of cylinder 1 compression stroke.

Plunger pre-lift for timing on engine: 1 mm from BDC (with tools **380000228 - 380001601**).

Cylinder no. 1 delivery line union on pump: marked with letter A.

### ASSEMBLY DIMENSIONS

SYMBOL	K	KF	MS1	ya	yb
mm	3.6 to 3.8	3	0.85 to 1.15	36.9 to 40.9	41.5 to 46.5

Test bench conforming to ISO 4008/1.../2

Injectors conforming to ISO 7440-A61 - (1688901027 with pad  $\varnothing$  0.5 mm)

Injector setting pressure: 250 bar (3625.925 psi).

Fuel supply pressure:  $0.35 \pm 0.05$  bar (kg/cm<sup>2</sup>). (5.0763  $\pm$  0.7252 psi).

Delivery pipes (conforming to ISO 4093.2):

6 x 2 x 450 mm (0.2362 x 0.787 x 17.7165 in.).

Graduate drain time: 30 seconds

Test liquid: ISO 4113 at a temperature of  $55^\circ \pm 1^\circ\text{C}$  ( $131^\circ \pm 33.8^\circ\text{F}$ ).

### CALIBRATION TEST CONDITIONS

#### 1. START OF DELIVERY

Plunger pre-lift from BDC: mm -	Pump rotation (viewed from drive side): anticlockwise	Injection order: 1-2-3
---------------------------------	---	------------------------

#### 2. ADVANCE REGULATOR STROKE

rpm: 1150	Advance stroke: mm 1.6 to 2.0
-----------	-------------------------------

#### 3. FUEL SUPPLY PUMP PRESSURE

rpm: 1150	Internal pressure: bar 8.4 to 8.8
-----------	-----------------------------------

#### 4. FULL LOAD DELIVERY

rpm: 800	Delivery per 1000 shots: cm <sup>3</sup> 77.3 to 77.7	Spread: cm <sup>3</sup> -
----------	---	---------------------------

#### 5. SPREAD GOVERNOR AT IDLE SPEED

rpm: 325	Delivery per 1000 shots: cm <sup>3</sup> 9.5 to 10.5	Spread: cm <sup>3</sup> $\leq$ 5.0
----------	--	------------------------------------

#### 6. SPREAD GOVERNOR AT MAXIMUM SPEED

rpm: 1300	Delivery per 1000 shots: cm <sup>3</sup> 49.5 to 50.5	Spread: -
-----------	---	-----------

#### 7. DELIVERY AT STARTING SPEED

rpm: 100	Delivery per 1000 shots: cm <sup>3</sup> 70 to 110
----------	--

#### 8. INJECTION ADVANCE PROGRESSION

Rev/min		1250	1150	1050
Advance stroke	mm	1.9 to 2.9	1.6 to 2.0	0.8 to 1.6

#### 9. TRANSFER PRESSURE PROGRESSION

Rev/min		500	1150	-
Internal pressure	bar	4.8 to 5.8	8.4 to 8.8	-

#### 10. BACKFLOW

Rev/min		500	1250
Backflow	cm <sup>3</sup> /10 s	44.5 to 77.7	58.3 to 97.1

(continued)

Note: The values shown above in brackets must be used for checking purposes only.

(continued)

**11. DELIVERY PROGRESSION**

Rev/min	Delivery per 1000 shots: cm <sup>3</sup>
1390	0 to 3
1300	49.5 to 50.5
1250	63.5 to 68.5
800	77.3 to 77.7
450	68,0

**12. ZERO DELIVERY (STOP)**

Rev/min	Voltage (volts)	Delivery per 1000 shots: cm <sup>3</sup>
325	0	0 to 3

**13. DELIVERY CHECK AT IDLE SPEED**

Rev/min	250	325	390
Delivery per 1000 shots: cm <sup>3</sup>	35	9.5 to 10.5	0 to 3.0

**14. AUTOMATIC START SUPPLEMENT**

Rev/min	Delivery per 1000 shots: cm <sup>3</sup>
100	70 to 110
250	67 to 77

Note: The values shown above in brackets must be used for checking purposes only.

**BENCH TEST PERFORMANCE DATA**

BENCH TEST PERFORMANCE DATA					
Test Conditions			Relative humidity 70% ± 5.		
TDC fixed advance with cylinder No. 1 in compression stroke: (see previous page).			Ambient temperature 25 °C.		
Engine without fan, air filter and exhaust silencer.			Specific gravity of diesel fuel 830 ± 10 g/litre.		
Atmospheric pressure: 990 mbar					
Throttle lever position	Braking load applied	Engine rpm	Power output with engine run-in for a total of:		Fuel consumption kg/h
			2 hours kW (HP)	50 hours kW	
Maximum	For maximum torque	2500	-	39,5 - 42,0	9,1 - 9,7
Maximum	For maximum torque	1500	-	31,5 - 33,5	6,8 - 7,2
Maximum	None (no-load)	2770 ± 25	-	-	-
Minimum	None (no-load)	650 ± 25	-	-	-

## JX70 MODEL - CALIBRATION DATA FOR BOSCH INJECTION PUMP TYPE VE 3/12 F 1250 L 977 - 504054474

### ASSEMBLY DATA

Pump timing on engine: delivery start  $0^\circ \pm 0.5^\circ$  before TDC of cylinder 1 compression stroke.  
Plunger pre-lift for pump timing on engine: 1 mm from BDC with tools **380000228 - 380001601**).  
Delivery line union on pump for cylinder no. 1: marked with letter A.

### ASSEMBLY DIMENSIONS

SYMBOL	K	KF	MS	ya	yb
mm	3.6 to 3.8	3	0.5 to 0.9	35.5 to 39.5	39.8 to 44.8

Test bench conforming to ISO 4008/1.../2  
Injectors conforming to ISO 7440-A61 - (1688901027 with pad  $\varnothing$  0.5 mm (0.0197 in.))  
Injector setting pressure: 250 bar (3625.925 psi).  
Fuel supply pressure:  $0.35 \pm 0.05$  bar (5.0763  $\pm$  0.7252 psi).  
Delivery pipes (conforming to ISO 4093.2): 6 x 2 x 450 mm (0.2362 x 0.787 x 17.7165 in.)  
Graduate drain time: 30 seconds  
Test liquid: ISO 4113 at a temperature of  $55^\circ \pm 1^\circ\text{C}$  ( $131^\circ \pm 33.8^\circ\text{F}$ ).

### CALIBRATION TEST CONDITIONS

#### 1. START OF DELIVERY

Plunger pre-lift from B.D.C.: mm -	Pump rotation (viewed from drive side): anticlockwise	Injection order:1-2-3
------------------------------------	--	-----------------------

#### 2. ADVANCE REGULATOR STROKE

1100 rpm	LDA pressure: kPa 100	Advance stroke: mm 1.8 to 2.2
----------	-----------------------	-------------------------------

#### 3. FUEL SUPPLY PUMP PRESSURE

rpm: 800	LDA pressure: kPa 100	Internal pressure: bar 7.7 to 8.3
----------	-----------------------	-----------------------------------

#### 4. FULL-LOAD DELIVERY WITH BOOSTER PRESSURE

rpm: 900	LDA pressure: kPa 100	Delivery per 1000 shots: $\text{cm}^3$ 76.5 to 76.9	Spread: $\text{cm}^3 \leq 3.5$
----------	-----------------------	---	--------------------------------

#### 5. FULL-LOAD DELIVERY WITHOUT BOOSTER PRESSURE

rpm: 600	LDA pressure: kPa 0	Delivery per 1000 shots: $\text{cm}^3$ 73.8 to 74.2	Spread: $\text{cm}^3$ -
----------	---------------------	---	-------------------------

#### 6. SPREAD GOVERNOR AT IDLE SPEED

rpm: 325	LDA pressure: kPa 0	Delivery per 1000 shots: $\text{cm}^3$ 12 to 13	Spread: $\text{cm}^3 \leq 4.5$
----------	---------------------	---	--------------------------------

#### 7. SPREAD GOVERNOR AT MAXIMUM SPEED

rpm: 1350	LDA pressure: kPa 100	Delivery per 1000 shots: $\text{cm}^3$ 32.0 to 33.0	Spread: $\text{cm}^3$ -
-----------	-----------------------	---	-------------------------

#### 8. DELIVERY AT STARTING SPEED

rpm: 100	Delivery per 1000 shots: $\text{cm}^3$ 100 to 140
----------	---

#### 9. INJECTION ADVANCE PROGRESSION

LDA pressure	kPa	100		
Rev/min		1250	1100	900
Advance stroke	mm	2.5 to 3.5	1.8 to 2.2	0.3 to 1.3

#### 10. TRANSFER PRESSURE PROGRESSION

LDA pressure	kPa	100		
Rev/min		1250	1100	500
Internal pressure supply:	bar	8,7	7.7 to 8.3	4.5 to 5.5

#### 11. BACKFLOW

Rev/min		1250	500
LDA pressure	kPa	100	100
Backflow for	$\text{cm}^3/10$ s	66.7 to 105.5	50.0 to 77.6

(continued)

Note: The values shown above in brackets must be used for checking purposes only.



(continued)

**12. DELIVERY PROGRESSION**

Rev/min	LDA pressure kPa	Delivery per 1000 shots: cm <sup>3</sup>
1390	100	0 to 3.0
1350	100	32 to 33
1250	100	66 to 71
900	100	76.5 to 76.9
600	27,5	76.2 to 77.2
400	100	91
600	0	73.8 to 74.2

**13. ZERO DELIVERY (STOP)**

rpm: 325	Voltage (volts): 0	Delivery per 1000 shots: cm <sup>3</sup> : 0 to 3
----------	--------------------	---

**14. DELIVERY CHECK AT IDLE SPEED**

Rev/min	325	380	-
Delivery per 1000 shots: cm <sup>3</sup>	12 to 13	0 to 3.0	-

**15. AUTOMATIC START SUPPLEMENT**

Rev/min	Delivery per 1000 shots: cm <sup>3</sup>
100	100 to 140
300	77 to 87

Note: The values shown above in brackets must be used for checking purposes only.

**BENCH TEST PERFORMANCE DATA**

BENCH TEST PERFORMANCE DATA					
Test Conditions			Relative humidity 70% ± 5.		
TDC fixed advance with cylinder No. 1 in compression stroke: (see previous page)			Ambient temperature 25 °C.		
Engine without fan, air filter and exhaust silencer.			Specific gravity of diesel fuel 830 ± 10 g/litre.		
Atmospheric pressure: 990 mbar					
Throttle lever position	Braking load applied	Engine rpm	Power output with engine run-in for a total of:		Fuel consumption kg/h
			2 hours kW (HP)	50 hours kW	
Maximum	For maximum torque	2500	-	47.5 - 50.5	11.1 - 11.8
Maximum	For maximum torque	1500	-	37.0 - 39.5	8.2 - 8.7
Maximum	None (no-load)	2770 ± 25	-	-	-
Minimum	None (no-load)	650 ± 25	-	-	-

## JX80 MODEL - CALIBRATION DATA FOR BOSCH INJECTION PUMP TYPE VE 4/12 F 1250 L 985 - 504041416

### ASSEMBLY DATA

Pump timing on engine: delivery start  $4^{\circ} \pm 0.5^{\circ}$  before T.D.C. of cylinder 1 on compression stroke.

Plunger pre-lift for timing on engine: 1 mm from BDC (with tools **380000228** - **380001601**).

Delivery union of the pump corresponding to cylinder no. 1: marked with letter A.

### ASSEMBLY DIMENSIONS

SYMBOL	K	A	MS	ya	yb
mm	3.64 to 3.76	1.4 to 1.5	0.5 to 0.9	38,9	43,0

### CALIBRATION TEST CONDITIONS

Test bench conforming to ISO 4008/1 .../2

Injectors conforming to ISO 7440-A61 - (1.688.901.027 with calibrated pad  $\varnothing$  0.5 mm (0.0197 in.)).

Injector pressure setting 250 to 253 bar (3625.925 to 3699.4361 psi)

Fuel supply pressure:

0.35  $\pm$  0.05 bar (5.0763  $\pm$  0.7252 psi).

Delivery pipes (conforming to ISO 4093.2):

6 x 2 x 450 mm (0.2362 x 0.787 x 17.7165 in.).

Graduate drain time : 30".

Test liquid: ISO 4113 at a temperature of  $55^{\circ} \pm 1^{\circ}\text{C}$  ( $131^{\circ} \pm 33.8^{\circ}\text{F}$ ).

### 1. START OF DELIVERY

Plunger pre-lift from BDC: mm -	Pump rotation (viewed from drive side): anticlockwise	Injection order: 1-3-4-2
---------------------------------	---	--------------------------

### 2. ADVANCE REGULATOR STROKE

rpm: 1250	Advance stroke: mm 2.0 to 3.2
-----------	-------------------------------

### 3. FUEL SUPPLY PUMP PRESSURE

rpm: 1000	Internal pressure: bar 6.7 to 8.1
-----------	-----------------------------------

### 4. FULL LOAD DELIVERY

rpm: 1000	Delivery per 1000 shots: $\text{cm}^3$ 65.2 to 70.3	Spread: $\text{cm}^3 \leq 3.5$
-----------	---	--------------------------------

### 5. SPREAD GOVERNOR AT IDLE SPEED

rpm: 325	Delivery per 1000 shots: $\text{cm}^3$ 4.0 to 18.0	Spread: $\text{cm}^3 \leq 4.5$
----------	--	--------------------------------

### 6. SPREAD GOVERNOR AT MAXIMUM SPEED

rpm: 1250	Delivery per 1000 shots: $\text{cm}^3$ 60.0 to 66.0	Spread:-
-----------	---	----------

### 7. DELIVERY AT STARTING SPEED

rpm: 100	Delivery per 1000 shots: $\text{cm}^3$ 75 to 115
----------	--

### 8. INJECTION ADVANCE PROGRESSION

Rev/min	1000	1250
Advance stroke mm	0.5 to 1.7	2.0 to 3.2

### 9. TRANSFER PRESSURE PROGRESSION

Rev/min	1000	400	
Internal pressure bar	6.7 to 8.1	4.1 to 5.5	

### 10. BACKFLOW

Rev/min	400	1250
Backflow l/h	16 to 30	21 to 39

(continued)

Note: The values shown above in brackets must be used for checking purposes only.

(continued)

**11. DELIVERY PROGRESSION**

Rev/min	Delivery per 1000 shots: cm <sup>3</sup>
1400	0 to 3
1250	60.0 to 66.0
1000	65.2 to 70.3
450	63.5 to 70.3

**12. ZERO DELIVERY (STOP)**

Rev/min	Voltage (volts)	Delivery per 1000 shots: cm <sup>3</sup>
325	0	0 to 3

**13. DELIVERY CHECK AT IDLE SPEED**

Rev/min	325	380	-
Delivery per 1000 shots: cm <sup>3</sup>	4.0 to 18.0	0 to 3.0	-

**14. AUTOMATIC START SUPPLEMENT**

Rev/min	Delivery per 1000 shots: cm <sup>3</sup>
100	75 to 115
250	60.5 to 74.5

Note: The values shown above in brackets must be used for checking purposes only.

**BENCH TEST PERFORMANCE DATA**

BENCH TEST PERFORMANCE DATA					
Test Conditions			Relative humidity 70% ± 5.		
TDC fixed advance with cylinder No. 1 in compression stroke: (see previous page)			Ambient temperature 25 °C.		
Engine without fan, air filter and exhaust silencer.			Specific gravity of diesel fuel 830 ± 10 g/litre.		
Atmospheric pressure: 990 mbar					
Throttle lever position	Braking load applied	Engine rpm	Power output with engine run-in for a total of:		Fuel consumption kg/h
			2 hours kW (HP)	50 hours kW (HP)	
Maximum	For maximum torque	2500	-	54.0 - 57.5	12.3 - 13.1
Maximum	For maximum torque	1500	-	39.5 - 42	8.5 - 9.0
Maximum	None (no-load)	2725 ± 25	-	-	-
Minimum	None (no-load)	650 ± 25	-	-	-

## JX90 MODEL - CALIBRATION DATA FOR BOSCH INJECTION PUMP TYPE VE 4/12 F 1250 L 982 - 504042214

### ASSEMBLY DATA

Pump timing on engine: delivery start  $1^{\circ} \pm 0.5^{\circ}$  before T.D.C. of cylinder 1 on compression stroke.

Plunger pre-lift for timing on engine: 1 mm from BDC (with tools **380000228** - **380001601**).

Delivery union of the pump corresponding to cylinder no. 1: marked with letter A.

### ASSEMBLY DIMENSIONS

SYMBOL	K	A	MS	ya	yb
mm	3.64 to 3.76	1.4 to 1.5	0.7 to 0.9	37.9 to 39.9	39.3 to 44.7

### CALIBRATION TEST CONDITIONS

Test bench conforming to ISO 4008/1 .../2

Injectors conforming to ISO 7440-A61 - (1.688.901.027 with calibrated pad  $\varnothing$  0.5 mm (0.0197 in.)).

Injector pressure setting 250 to 253 bar (3625.925 to 3741.9546 psi).

Fuel supply pressure:

0.35  $\pm$  0.05 bar (5.0763  $\pm$  0.7252 psi).

Delivery pipes (conforming to ISO 4093.2):

6 x 2 x 450 mm (0.2362 x 0.787 x 17.7165 in.).

Graduate drain time : 30".

Test liquid: ISO 4113 at a temperature of  $55^{\circ} \pm 1^{\circ}\text{C}$  ( $131^{\circ} \pm 33.8^{\circ}\text{F}$ ).

#### 1. START OF DELIVERY

Plunger pre-lift from BDC: mm -	Pump rotation (viewed from drive side): anticlockwise	Injection order: 1-3-4-2
---------------------------------	---	--------------------------

#### 2. ADVANCE REGULATOR STROKE

rpm: 1250	Advance stroke: mm 2.4 to 3.6
-----------	-------------------------------

#### 3. FUEL SUPPLY PUMP PRESSURE

rpm: 1250	Internal pressure: bar 8.7 to 10.1
-----------	------------------------------------

#### 4. FULL LOAD DELIVERY

rpm: 900	Delivery per 1000 shots: $\text{cm}^3$ 77.5 to 82.5	Spread: $\text{cm}^3 \leq 3.5$
----------	---	--------------------------------

#### 5. SPREAD GOVERNOR AT IDLE SPEED

rpm: 375	Delivery per 1000 shots: $\text{cm}^3$ 5.5 to 19.5	Spread: $\text{cm}^3 \leq 4.5$
----------	--	--------------------------------

#### 6. SPREAD GOVERNOR AT MAXIMUM SPEED

rpm: 1250	Delivery per 1000 shots: $\text{cm}^3$ 69.5 to 75.5	Spread:-
-----------	---	----------

#### 7. DELIVERY AT STARTING SPEED

rpm: 100	Delivery per 1000 shots: $\text{cm}^3$ 80 to 120
----------	--

#### 8. INJECTION ADVANCE PROGRESSION

Rev/min	1000	1250
Advance stroke mm	0.2 to 1.0	2.4 to 3.6

#### 9. TRANSFER PRESSURE PROGRESSION

Rev/min	1250	400	
Internal pressure bar	8.7 to 10.1	3.6 to 5.0	

#### 10. BACKFLOW

Rev/min	400	1250
Backflow l/h	15 to 29	22 to 40

(continued)

Note: The values shown above in brackets must be used for checking purposes only.

(continued)

**11. DELIVERY PROGRESSION**

Rev/min	Delivery per 1000 shots: cm <sup>3</sup>
1400	0 to 3
1250	69.5 to 75.5
900	77.5 to 82.5
400	76.5 to 83.5

**12. ZERO DELIVERY (STOP)**

Rev/min	Voltage (volts)	Delivery per 1000 shots: cm <sup>3</sup>
375	0	0 to 3

**13. DELIVERY CHECK AT IDLE SPEED**

Rev/min	375	425	-
Delivery per 1000 shots: cm <sup>3</sup>	5.5 to 19.5	0 to 3.0	-

**14. AUTOMATIC START SUPPLEMENT**

Rev/min	Delivery per 1000 shots: cm <sup>3</sup>
100	80 to 120
275	68 to 92

Note: The values shown above in brackets must be used for checking purposes only.

**BENCH TEST PERFORMANCE DATA**

BENCH TEST PERFORMANCE DATA					
Test Conditions			Test Conditions		
TDC fixed advance with cylinder No. 1 in compression stroke: (see previous page)			Relative humidity 70% ± 5.		
Engine without fan, air filter and exhaust silencer.			Ambient temperature 25 °C.		
Atmospheric pressure: 990 mbar			Specific gravity of diesel fuel 830 ± 10 g/litre.		
Throttle lever position	Braking load applied	Engine rpm	Power output with engine run-in for a total of:		Fuel consumption kg/h
			2 hours kW (HP)	50 hours kW (HP)	
Maximum	For maximum torque	2500	-	60.0 - 64.0	13.7 - 14.6
Maximum	For maximum torque	1500	-	46.0 - 48.8	9.8 - 10.4
Maximum	None (no-load)	2725 ± 25	-	-	-
Minimum	None (no-load)	650 ± 25	-	-	-

## JX95 MODEL - CALIBRATION DATA FOR BOSCH INJECTION PUMP TYPE VE 4/12 F 1250 L 952 - 504042718

### ASSEMBLY DATA

Pump timing on engine: delivery start  $0^{\circ} \pm 0.5^{\circ}$  before T.D.C. of cylinder 1 on compression stroke.

Plunger pre-lift for timing on engine: 1 mm from BDC (with tools **380000228** - **380001601**).

Delivery union of the pump corresponding to cylinder no. 1: marked with letter A.

### ASSEMBLY DIMENSIONS

SYMBOL	K	A	MS	ya	yb
mm	3.64 to 3.76	0.98 to 1.02	0.6 to 1.0	36.5 to 38.5	41.3 to 46.7

### CALIBRATION TEST CONDITIONS

Test bench conforming to ISO 4008/1 .../2

Injectors conforming to ISO 7440-A61 - (1.688.901.027 with calibrated pad  $\varnothing$  0.5 mm) (0.0197 in.).

Injector pressure setting 250 to 253 bar (3625.925 to 3741.9546 psi).

Fuel supply pressure:

0.35  $\pm$  0.05 bar (5.0763  $\pm$  0.7252 psi).

Delivery pipes (conforming to ISO 4093.2):

6 x 2 x 450 mm (0.2362 x 0.787 x 17.7165 in.).

Graduate drain time : 30".

Test liquid: ISO 4113 at a temperature of  $55^{\circ} \pm 1^{\circ}\text{C}$  ( $131^{\circ} \pm 33.8^{\circ}\text{F}$ ).

### 1. START OF DELIVERY

Plunger pre-lift from B.D.C.: mm -	Pump rotation (viewed from drive side): anticlockwise	Injection order:1-3-4-2
------------------------------------	--	-------------------------

### 2. ADVANCE REGULATOR STROKE

rpm: 1250	LDA pressure: kPa 100	Advance stroke: mm 2.2 to 3.4
-----------	-----------------------	-------------------------------

### 3. FUEL SUPPLY PUMP PRESSURE

1100 rpm	LDA pressure: kPa 100	Internal pressure: bar 6.5 to 7.9
----------	-----------------------	-----------------------------------

### 4. FULL-LOAD DELIVERY WITH BOOSTER PRESSURE

rpm: 900	LDA pressure: kPa 100	Delivery per 1000 shots: $\text{cm}^3$ 75.5 to 80.5	Spread: $\text{cm}^3 \leq 3.5$
----------	-----------------------	---	--------------------------------

### 5. FULL-LOAD DELIVERY WITHOUT BOOSTER PRESSURE

rpm: 500	LDA pressure: kPa 0	Delivery per 1000 shots: $\text{cm}^3$ 66.0 to 72.0	Spread: $\text{cm}^3$ -
----------	---------------------	---	-------------------------

### 6. SPREAD GOVERNOR AT IDLE SPEED

rpm: 350	LDA pressure: kPa 0	Delivery per 1000 shots: $\text{cm}^3$ 8 to 23	Spread: $\text{cm}^3 \leq 5.5$
----------	---------------------	--	--------------------------------

### 7. SPREAD GOVERNOR AT MAXIMUM SPEED

rpm: 1250	LDA pressure: kPa 100	Delivery per 1000 shots: $\text{cm}^3$ 66.0 to 72.0	Spread: $\text{cm}^3$ -
-----------	-----------------------	---	-------------------------

### 8. DELIVERY AT STARTING SPEED

rpm: 100	Delivery per 1000 shots: $\text{cm}^3$ 75 to 115
----------	--

### 9. INJECTION ADVANCE PROGRESSION

LDA pressure	kPa	100	
Rev/min		1100	1250
Advance stroke	mm	1.4 to 2.6	2.2 to 3.4

### 10. TRANSFER PRESSURE PROGRESSION

LDA pressure	kPa	100	
Rev/min		500	1100
Internal pressure supply:	bar	4.1 to 5.5	6.5 to 7.9

### 11. BACKFLOW

Rev/min		500	1250
LDA pressure	kPa	100	100
Backflow for 10 sec.	l/h	18 to 32	21 to 39

(continued)

Note: The values shown above in brackets must be used for checking purposes only.

Please click here and go  
back to our website.

**BUY NOW**

Then Instant Download the  
Complete Manual.

Thank you very much!