

<https://caseih.servicemanual.com>

836C
836C AWD
856C
856C AWD
Stage IV
Motor Grader

SERVICE MANUAL

Part number 47829048B
English
June 2016
© 2016 CNH Industrial Italia S.p.A. All Rights Reserved.





SERVICE MANUAL

836C AWD

836C

856C AWD

856C

<https://caseihservicemanual.com>

Link Product / Engine

Product	Market Product	Engine
836C	Europe	F4HFE6133*B003
836C AWD	Europe	F4HFE6133*B003
856C	Europe	F4HFE613Y*B003
856C AWD	Europe	F4HFE613Y*B003

<https://caseih.servicemanual.com>

Contents

INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase	10.1
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.2
[10.501] Exhaust Gas Recirculation (EGR) exhaust treatment.....	10.3
[10.400] Engine cooling system	10.4
[10.304] Engine lubrication system.....	10.5
Transmission.....	21
[21.113] Powershift transmission	21.1
[21.135] Powershift transmission external controls.....	21.2
[21.105] Powershift transmission lubrication system	21.3
[21.155] Powershift transmission internal components.....	21.4
[21.700] Torque converter	21.5
Front axle system	25
[25.100] Powered front axle	25.1
[25.108] Final drive hub, steering knuckles, and shafts	25.2
Rear axle system.....	27
[27.106] Rear bevel gear set and differential	27.1
[27.120] Planetary and final drives	27.2
[27.600] Tandem axle.....	27.3
[27.650] Chain drive system.....	27.4
Hydrostatic drive.....	29
[29.204] Reservoir, cooler, and lines	29.1
[29.218] Pump and motor components.....	29.2
Brakes and controls	33
[33.202] Hydraulic service brakes	33.1

[33.110] Parking brake or parking lock	33.2
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.300] Reservoir, cooler, and filters.....	35.2
[35.104] Fixed displacement pump.....	35.3
[35.102] Pump control valves.....	35.4
[35.105] Charge pump.....	35.5
[35.204] Remote control valves	35.6
[35.354] Hydraulic central joint	35.7
[35.739] Swing arm hydraulic system	35.8
[35.741] Dozer blade cylinders	35.9
[35.742] Ripper hydraulic system.....	35.10
[35.310] Distributor and lines	35.11
Frames and ballasting	39
[39.100] Frame	39.1
Steering.....	41
[41.200] Hydraulic control components.....	41.1
[41.206] Pump.....	41.2
[41.216] Cylinders	41.3
Wheels	44
[44.511] Front wheels.....	44.1
[44.520] Rear wheels.....	44.2
Cab climate control	50
[50.100] Heating.....	50.1
Electrical systems	55
[55.000] Electrical system	55.1
[55.100] Harnesses and connectors.....	55.2

[55.302] Battery.....	55.3
[55.988] Selective Catalytic Reduction (SCR) electrical system	55.4
[55.989] Exhaust Gas Recirculation (EGR) electrical system	55.5
[55.640] Electronic modules	55.6
[55.512] Cab controls	55.7
[55.530] Camera.....	55.8
[55.408] Warning indicators, alarms, and instruments	55.9
[55.DTC] FAULT CODES.....	55.10
Dozer blade and arm.....	86
[86.110] Dozer blade	86.1
[86.112] Moldboard blade	86.2
Tools	89
[89.128] Ripper assembly	89.1
Platform, cab, bodywork, and decals.....	90
[90.150] Cab.....	90.1
[90.120] Mechanically-adjusted operator seat.....	90.2
[90.100] Engine hood and panels	90.3

<https://casehservicemanual.com>

<https://caseih.servicemanual.com>



INTRODUCTION

<https://caseihservicemanual.com>

Contents

INTRODUCTION

Foreword - Important notice regarding equipment servicing	3
Safety rules (*)	4
Personal safety	5
Torque - Minimum tightening torques for normal assembly	14
Torque - Standard torque data for hydraulics	15
Special tools	22
Basic instructions - Shop and assembly	27
Basic instructions - Precaution for disassembly and assembly	29
Basic instructions - Electrical equipment precautions	31
Basic instructions - Hydraulic contamination	32
Basic instructions - Biodiesel fuel	33
Capacities	35
Consumables	36
Product identification	46
Product identification - Machine orientation	52

<https://caseih.servicemanual.com>

(*) See content for specific models

Foreword - Important notice regarding equipment servicing

All repair and maintenance work listed in this manual must be carried out only by qualified dealership personnel, strictly complying with the instructions given, and using, whenever possible, the special tools.

Anyone who performs repair and maintenance operations without complying with the procedures provided herein shall be responsible for any subsequent damages.

The manufacturer and all the organizations of its distribution chain, including - without limitation - national, regional, or local dealers, reject any responsibility for damages caused by parts and/or components not approved by the manufacturer, including those used for the servicing or repair of the product manufactured or marketed by the manufacturer. In any case, no warranty is given or attributed on the product manufactured or marketed by the manufacturer in case of damages caused by parts and/or components not approved by the manufacturer.

The manufacturer reserves the right to make improvements in design and changes in specifications at any time without notice and without incurring any obligation to install them on units previously sold. Specifications, descriptions, and illustrative material herein are as accurate as known at time of publication but are subject to change without notice.

In case of questions, refer to your CASE CONSTRUCTION Sales and Service Networks.

<https://caseihservicemanual.com>

Safety rules

800C

WE


Personal safety





This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible death or injury.

Throughout this manual you will find the signal words DANGER, WARNING, and CAUTION followed by special instructions. These precautions are intended for the personal safety of you and those working with you.

Read and understand all the safety messages in this manual before you operate or service the machine.

 DANGER indicates a hazardous situation that, if not avoided, will result in death or serious injury.

 WARNING indicates a hazardous situation that, if not avoided, could result in death or serious injury.

 CAUTION indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

FAILURE TO FOLLOW DANGER, WARNING, AND CAUTION MESSAGES COULD RESULT IN DEATH OR SERIOUS INJURY.

Machine safety

NOTICE: Notice indicates a situation that, if not avoided, could result in machine or property damage.

Throughout this manual you will find the signal word Notice followed by special instructions to prevent machine or property damage. The word Notice is used to address practices not related to personal safety.

Information

NOTE: Note indicates additional information that clarifies steps, procedures, or other information in this manual.

Throughout this manual you will find the word Note followed by additional information about a step, procedure, or other information in the manual. The word Note is not intended to address personal safety or property damage.

Personal safety

Carefully read this Manual before proceeding with maintenance, repairs, refuelling or other machine operations.

Repairs have to be carried out only by authorized and instructed staff; specific precautions have to be taken when grinding, welding or when using mallets or heavy hammers.

Not authorized persons are not allowed to repair or carry out maintenance on this machine. Do not carry out any work on the equipment without prior authorization.

Ask your employer about the safety instructions in force and safety equipment.

Nobody should be allowed in the cab during machine maintenance unless he is a qualified operator helping with the maintenance work.

If it is necessary to move the equipment to carry out repairs or maintenance, do not lift or lower the equipment from any other position than the operator's seat.

Never carry out any operation on the machine when the engine is running, except when specifically indicated.

Stop the engine and ensure that all pressure is relieved from hydraulic circuits before removing caps, covers, valves, etc.

All repair and maintenance operations should be carried out with the greatest care and attention.

Service stairs and platforms used in a workshop or in the field should be built in compliance with the safety rules in force.

Any functional disorders, especially those affecting the safety of the machine, should therefore be rectified immediately.

▲ DANGER


Unexpected movement!

Make sure parking brake is applied. Secure machine with wheel chocks.

Failure to comply will result in death or serious injury.

D0013A


Before performing any work on the machine, attach a maintenance in progress tag. This tag can be applied on the dashboard, on the cab door, or at any other well visible place.



TULI12WEX2004AA 1

Emergency

Be prepared for emergencies. Always keep a fire extinguisher and first aid kit readily available. Ensure that the fire extinguisher is serviced in accordance with the manufacturer's instructions.



SMIL12WEX0174AA 2

Equipment


Wear close fitting clothing and safety equipment appropriate for the job:

- Safety helmet
- Safety shoes
- Heavy gloves
- Reflective clothing
- Wet weather clothing

If working conditions require, the following personal safety equipment should be on hand:

- Respirators (or dust proof masks)
- Ear plugs or acoustic ears protections
- Goggles with lateral shield or masks for eyes protection

Do not wear rings, wristwatches, jewels, unbuttoned or flapping clothing such as ties, torn clothes, scarves, open jackets or shirts with open zips which could get caught into moving parts.



TUL12WEX2008AA 3


Engine - Radiator

Never leave the engine running in enclosed spaces without proper ventilation which is able to evacuate toxic exhaust gases. Keep the exhaust manifold and tube free from combustible materials.

Do not refuel with the engine running, especially if hot, as this increases fire hazard in case of fuel spillage.

Never attempt to check or adjust the belts when the engine is running.

Never lubricate the machine with the engine running.



TUL12WEX2009AA 4

Pay attention to rotating components and do not allow to anyone to approach these areas to avoid becoming entangled.


Hands, clothing or tools getting caught in the fan blades or transmission belts, can cause amputations, violent hemorrhages and generate conditions of grave danger. For this reason avoid touching or approaching all rotating or moving parts.

A surging spray of the coolant from the radiator can cause serious burns and scalds.


Before checking the coolant level, shut-off the engine and allow machine to cool down the radiator and hoses. Slowly unscrew the cap to release any residual pressure.

If it is necessary to remove the cap while engine is hot, wear safety clothes and equipment, then loosen the cap slowly to relieve the pressure gradually.

When checking the fuel, oil and coolant levels, use lights and lamps explicitly designated as explosion proof. If these types of lamps are not use, fires or explosions may occur.



TULI12WEX2010AA 5



TULI12WEX2011AA 6

Hydraulic systems

Jets of fluids under pressure can penetrate the skin causing serious injuries.

Avoid this hazard by relieving pressure before disconnecting hydraulic or other lines.

Relieve the residual pressure by moving the hydraulic control levers several times.

Tighten all connections before applying pressure.

To protect the eyes wear a facial shield or safety goggles.

Protect your hands and body from possible jets of fluids under pressure.

Swallowing hydraulic oil is a severe health hazard.



TULI12WEX2012AA 7

INTRODUCTION

When hydraulic oil has been swallowed, avoid vomiting, but consult a doctor or go to a hospital.

If an accident occurs, see a doctor familiar with this type of injury immediately.

Any fluid penetrating the skin must be removed within few hours to avoid serious infections.

Flammable splashes may originate because of heating near lines with fluids under pressure, resulting in serious burns. Do not weld or use torches near lines containing fluids or other flammable materials.

Lines under pressure can accidentally be pierced when the heat expands beyond the area immediately heated.

Arrange for temporary fire resistant shields to protect hoses or other components during welding or torch use.


Have any visible leakage repaired immediately.

Discharged oil pollutes the environment. Soak up any oil that has spilled with a proper binding agent. Sweep up binding agent and dispose of it separately from other waste.

Never search for leakages with fingers; instead, use a piece of cardboard and always wear goggles.

Never repair a damaged line; always replace it. Replace hydraulic hoses immediately on detecting any damaged or moist areas.

Always store hydraulic oil in the original containers.



TUL112WEX2013AA 8

<https://caseih.servicemanual.com>

Hoses and tubes

Always replace hoses and tubes if the cone end or the end connections on the hose are damaged.

When installing a new hose, loosely connect each end and make sure the hose takes up the correct position before tightening the connections. Clamps should be tightened sufficiently to hold the hose without crushing and to prevent chafing.

After hose replacement to a moving component, check that the hose does not foul by moving the component through the complete range of travel. Be sure any hose which has been installed is not kinked or twisted.

Hose connections which are damaged, dented, crushed or leaking, restrict oil flow and the productivity of the components being served. Connectors which show signs of movement from the original position have failed and will ultimately separate completely.

A hose with a frayed outer sheath will allow water penetration. Concealed corrosion of the wire reinforcement could subsequently occur along the hose length with resultant hose failure.

Ballooning of the hose indicates an internal leakage due to structural failure. This condition rapidly deteriorates and total hose failure soon occurs.

Kinked, crushed, stretched or deformed hoses generally suffer internal structural damage which can result in oil restriction, a reduction in the speed of operation and ultimate hose failure.


Free-moving, unsupported hoses must never be allowed to touch each other or related working surfaces. This causes chafing which reduces hose life.

O-rings

Replace O-rings, seal rings and gaskets whenever they are disassembled.

Never mix new and old seals or O-rings, regardless of condition. Always lubricate new seal rings and O-rings with hydraulic oil before installation to relevant seats.

This will prevent the O-rings from rolling over and twisting during mounting which will jeopardize sealing.



TULI12WEX2014AA 9

Battery

Batteries give off explosive gases.

Never handle naked flames and unshielded light sources near batteries. (No smoking is addressed in next instruction).

To prevent any risk of explosion, observe the following instructions:

- When disconnecting the battery cables, always disconnect the negative (-) cable first.
- To reconnect the battery cables, always connect the negative (-) cable last.
- Never short-circuit the battery terminals with metal objects.
- Do not weld, grind or smoke near a battery.

Battery electrolyte causes severe burns. The battery contains sulphuric acid. Avoid any contact with the skin, eyes or clothing.

Antidote:


- EXTERNAL: Rinse well with water, removing any soiled clothing.
- INTERNAL: Avoid vomiting. Drink water to rinse your mouth. Consult a doctor.
- EYES: Rinse abundantly with water for **15 min** and consult a doctor.
- When the electrolyte of a battery is frozen, it can explode if you attempt to charge the battery or if you try to start the engine using a booster battery. Always keep the battery charged to prevent the electrolyte freezing.

Provide good ventilation when changing a battery or using a battery in an enclosed space. Always protect your eyes when working near a battery.

Never set tools down on the battery. They may induce a short circuit, causing irreparable damage to the battery and injuring persons.

Never wear metal necklaces, bracelets or watch straps when working on the battery. The metal parts may induce a short circuit resulting in burns.


Dispose of used batteries separately from other waste in the interests of environmental protection.



TUL112WEX2015AA 10



TUL112WEX2016AA 11



TUL112WEX2017AA 12

Flammable liquids

When handling flammable liquids:

- Do not smoke.
- Keep away from unshielded light sources and naked flames.

Fuels often have a low flash point and are readily ignited.

Never attempt to extinguish burning liquids with water.
Use:

- Dry powder
- Carbon dioxide
- Foam

Water used for extinguishing purposes would vaporize instantaneously on contact with burning substances and spread burning oil, for example, over a wide area. Water generates short circuits in the electrical system, possibly producing new hazards.

Stay away from open flames during refilling of hydraulic oil or fuel.

Fuel or oil spills can cause slipping hazards; thoroughly contain and clean affected areas.

Always tighten the safety plugs of fuel tank and hydraulic oil tank firmly.

Never use fuel to clean machine parts that will be exposed to dirt or debris.

Use a non-flammable product for cleaning parts.


Always perform fuel or oil refilling in well aired and ventilated areas.

During refuelling hold the pistol firmly and always keep it in contact with the filler neck until the end of the refuelling, to avoid arcing due to static electricity.

Do not overfill the tank but leave a space for fuel expansion.

Never refuel when the engine is running.

Take all the necessary safety measures when welding, grinding or when working near a naked flame.



TUL12WEX2016AA 13



TUL12WEX2018AA 14



TUL12WEX2019AA 15

Tires


Before inflating the tires, always check the condition of rims and the outer condition of tires to find out the presence of dents, cuts, tears of reinforcement plies or other faults. Before inflating a tire, make sure that there are no nearby persons, then position yourself at tread side.

When inflating tires, ensure tire pressure does not exceed that prescribed by the tire manufacturer. Ensure that the pressure of the right tire corresponds to the pressure of the left tire.

NOTE: The front and rear tire pressures may be different.

Never use reconditioned rims because possible welds, heat treatments or brazings not performed correctly can weaken the wheels and cause following damages or failures. Deflate the tires before their disassembly.

Before taking out possible jammed objects from the rims, it is necessary to deflate the tires. Inflate tires by means of an inflation pistol complete with extension and pressure control valve.



TUL112WEX2020AA 16

Cleaning

Clean the exterior of all components before carrying out any form of repair. Dirt and dust can reduce the efficient working life of a component and lead to costly replacement.


Solvents should be checked that they are suitable for the cleaning of components and also that they do not risk the personal safety of the user.

Dirt, oil, grease and scattered tools are dangerous for people, because they can create slipping or tripping hazards.

For machine cleaning, use a jet of warm water or steam under pressure and commercial detergents. Never use fuel, petroleum or solvents, because they can leave an oily residue that attracts dust, and solvents (even if weak) damage the paint and can lead to the information of rust.

Never use water jets or steam on sensors, connectors or other electric components.

Avoid direct spray of seals and seams to prevent water penetration inside the cab.



TUL112WEX2021AA 17

Waste disposal

Improperly disposing of waste can threaten the environment.

Each country has its own regulations on this subject. It is therefore advisable to prepare suitable containers to collect and store momentarily all solid and fluid materials that must not be scattered in the environment to avoid pollution.


At preset intervals these products will be delivered to disposal stations legally recognized and present in this country.

Hereunder are listed some products of the machine requiring disposal:

- Lubricating oil
- Brake system oil
- Coolant mixture, condensation rests and pure antifreeze
- Fuel
- Filter elements, oil and fuel filters
- Filter elements, air filters
- Battery

Also polluting rags, paper, sawdust and gloves must be disposed in compliance with the same procedures.

Do not use food or beverage containers that may mislead someone into drinking from them. Do not pour waste onto the ground, down a drain, or into any water source. Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service centre to recover and recycle used air conditioning refrigerants. Obtain information on the proper way to recycle or dispose of waste from your local environmental or recycling centre, or from your Dealer.



TUL112WEX2022AA 18


Torque - Minimum tightening torques for normal assembly

Use the torques in this chart when special torques are not given. These torques apply to plain and zinc-dichromate fasteners as received from suppliers dry, or when lubricated with engine oil. Not applicable if special graphite lubricants, Molydisulfide greases, or other extreme pressure lubricants are used. A torque range of $\pm 10\%$ is acceptable.

Grade 8.8 bolts, nuts, and studs

Size	Nm	lb ft
4 mm	4 N·m	3 lb ft
5 mm	7 N·m	5 lb ft
6 mm	12 N·m	9 lb ft
8 mm	29 N·m	21 lb ft
10 mm	57 N·m	42 lb ft
12 mm	100 N·m	74 lb ft
14 mm	159 N·m	117 lb ft
16 mm	248 N·m	183 lb ft
18 mm	352 N·m	260 lb ft
20 mm	500 N·m	369 lb ft
22 mm	681 N·m	502 lb ft
24 mm	865 N·m	638 lb ft
27 mm	1262 N·m	931 lb ft
30 mm	1719 N·m	1268 lb ft
36 mm	2999 N·m	2212 lb ft


Markings for Grade 8.8 hardware




Grade 10.9 bolts, nuts and studs

Size	Nm	lb ft
4 mm	5 N·m	4 lb ft
5 mm	10 N·m	7 lb ft
6 mm	17 N·m	13 lb ft
8 mm	41 N·m	31 lb ft
10 mm	82 N·m	60 lb ft
12 mm	143 N·m	105 lb ft
14 mm	227 N·m	168 lb ft
16 mm	354 N·m	261 lb ft
18 mm	487 N·m	359 lb ft
20 mm	690 N·m	509 lb ft
22 mm	942 N·m	695 lb ft
24 mm	1195 N·m	882 lb ft
27 mm	1749 N·m	1290 lb ft
30 mm	2377 N·m	1753 lb ft
36 mm	4149 N·m	3061 lb ft

Markings for Grade 10.9 hardware



Grade 12.9 bolts, nuts, and studs

Torque values specified for grade 10.9 hardware can be used for grade 12.9 hardware.
Markings for Grade 12.9 hardware


Torque - Standard torque data for hydraulics

Use the torques in the charts when special torques are not given.
The torque values are based on catalogue data provided by the hydraulic fitting manufacturers.
If the manufacturer is unknown apply the "Recommended" torque.

NOTE:

- a) The torque values are applicable on all carbon steel components in which the external surface is protected with an appropriate coating (zinc plating). Changes in plating may affect assembly torques.
- b) For steel fittings into aluminum or cast iron components the torque may differ (e.g. depending on depth of thread engagement)!
- c) Not applicable if special graphite lubricants, Molydisulfide greases, or other extreme pressure lubricants are used.

The assembly of the fitting and connector shall be carried out without external loads. Screw up hand-tight and then tighten further with a spanner according to the values mentioned in the tables on the next pages. Ensure that in all cases the fitting or hose is correctly aligned before tightening onto the corresponding adaptor.


The fitting manufacturers which are not listed on the torque charts shall draw up assembly instructions for the use of the connectors. These instructions shall include at least the following:

- Details relating to material and quality of suitable tubes
- Details concerning the preparation of the selected tube
- Instructions regarding the assembly of the connector, such as the number of wrenching turns or assembly torque
- Recommendations regarding the tools to be used for assembly

1. Stud connector for ports with elastomeric sealing (Type E)

NOTE:

- The torque chart give recommendations to threaded connectors in steel with a zinc-coated surface.
- For steel fittings into aluminum components the torque is **70 %** of the below values.



SS14G152 1

INTRODUCTION

Stud end with elastomeric sealing (type E) according ISO 9974-2

Series	Tube outer diameter	Thread size (d)	Recommended	PARKER	VOSS
Light (L)	6 mm	M10 x 1	18 N·m (13 lb ft)	18 N·m (13 lb ft)	15 N·m (11 lb ft)
Light (L)	8 mm	M12 x 1.5	25 N·m (18 lb ft)	25 N·m (18 lb ft)	25 N·m (18 lb ft)
Light (L)	10 mm	M14 x 1.5	45 N·m (33 lb ft)	45 N·m (33 lb ft)	50 N·m (37 lb ft)
Light (L)	12 mm	M16 x 1.5	60 N·m (44 lb ft)	55 N·m (41 lb ft)	70 N·m (52 lb ft)
Light (L)	15 mm	M18 x 1.5	80 N·m (59 lb ft)	70 N·m (52 lb ft)	90 N·m (66 lb ft)
Light (L)	18 mm	M22 x 1.5	125 N·m (92 lb ft)	125 N·m (92 lb ft)	130 N·m (96 lb ft)
Light (L)	22 mm	M26 x 1.5	180 N·m (133 lb ft)	180 N·m (133 lb ft)	180 N·m (133 lb ft)
Light (L)	28 mm	M33 x 2	280 N·m (207 lb ft)	310 N·m (229 lb ft)	230 N·m (170 lb ft)
Light (L)	35 mm	M42 x 2	400 N·m (295 lb ft)	450 N·m (332 lb ft)	330 N·m (243 lb ft)
Light (L)	42 mm	M48 x 2	540 N·m (398 lb ft)	540 N·m (398 lb ft)	500 N·m (369 lb ft)

Stud end with elastomeric sealing (type E) according ISO 1179-2

Series	Tube outer diameter	Thread size (d)	Recommended	PARKER	VOSS
Light (L)	6 mm	G 1/8 A	18 N·m (13 lb ft)	18 N·m (13 lb ft)	20 N·m (15 lb ft)
Light (L)	8 mm	G 1/4 A	40 N·m (30 lb ft)	35 N·m (26 lb ft)	50 N·m (37 lb ft)
Light (L)	10 mm	G 1/4 A	40 N·m (30 lb ft)	35 N·m (26 lb ft)	50 N·m (37 lb ft)
Light (L)	12 mm	G 3/8 A	80 N·m (59 lb ft)	70 N·m (52 lb ft)	80 N·m (59 lb ft)
Light (L)	15 mm	G 1/2 A	100 N·m (74 lb ft)	90 N·m (66 lb ft)	100 N·m (74 lb ft)
Light (L)	18 mm	G 1/2 A	100 N·m (74 lb ft)	90 N·m (66 lb ft)	100 N·m (74 lb ft)
Light (L)	22 mm	G 3/4 A	180 N·m (133 lb ft)	180 N·m (133 lb ft)	180 N·m (133 lb ft)
Light (L)	28 mm	G 1 A	280 N·m (207 lb ft)	310 N·m (229 lb ft)	230 N·m (170 lb ft)
Light (L)	35 mm	G 1 1/4 A	400 N·m (295 lb ft)	450 N·m (332 lb ft)	330 N·m (243 lb ft)
Light (L)	42 mm	G 1 1/2 A	540 N·m (398 lb ft)	540 N·m (398 lb ft)	500 N·m (369 lb ft)

Stud end with elastomeric sealing (type E) according ISO 9974-2

Series	Tube outer diameter	Thread size (d)	Recommended	PARKER	VOSS
Heavy (S)	6 mm	M12 x 1.5	40 N·m (30 lb ft)	40 N·m (30 lb ft)	50 N·m (37 lb ft)
Heavy (S)	8 mm	M14 x 1.5	55 N·m (41 lb ft)	40 N·m (30 lb ft)	60 N·m (44 lb ft)
Heavy (S)	10 mm	M16 x 1.5	70 N·m (52 lb ft)	70 N·m (52 lb ft)	80 N·m (59 lb ft)
Heavy (S)	12 mm	M18 x 1.5	90 N·m (66 lb ft)	90 N·m (66 lb ft)	90 N·m (66 lb ft)
Heavy (S)	16 mm	M22 x 1.5	135 N·m (100 lb ft)	135 N·m (100 lb ft)	130 N·m (96 lb ft)
Heavy (S)	20 mm	M27 x 2	180 N·m (133 lb ft)	180 N·m (133 lb ft)	200 N·m (148 lb ft)
Heavy (S)	25 mm	M33 x 2	310 N·m (229 lb ft)	310 N·m (229 lb ft)	250 N·m (184 lb ft)
Heavy (S)	30 mm	M42 x 2	470 N·m (347 lb ft)	450 N·m (332 lb ft)	500 N·m (369 lb ft)
Heavy (S)	38 mm	M48 x 2	560 N·m (413 lb ft)	540 N·m (398 lb ft)	600 N·m (443 lb ft)

Stud end with elastomeric sealing (type E) according ISO 1179-2

Series	Tube outer diameter	Thread size (d)	Recommended	PARKER	VOSS
Heavy (S)	6 mm	G 1/4 A	50 N·m (37 lb ft)	40 N·m (30 lb ft)	60 N·m (44 lb ft)
Heavy (S)	8 mm	G 1/4 A	50 N·m (37 lb ft)	40 N·m (30 lb ft)	60 N·m (44 lb ft)
Heavy (S)	10 mm	G 3/8 A	80 N·m (59 lb ft)	80 N·m (59 lb ft)	90 N·m (66 lb ft)
Heavy (S)	12 mm	G 3/8 A	80 N·m (59 lb ft)	80 N·m (59 lb ft)	90 N·m (66 lb ft)
Heavy (S)	16 mm	G 1/2 A	120 N·m (89 lb ft)	115 N·m (85 lb ft)	150 N·m (111 lb ft)
Heavy (S)	20 mm	G 3/4 A	180 N·m (133 lb ft)	180 N·m (133 lb ft)	200 N·m (148 lb ft)
Heavy (S)	25 mm	G 1 A	300 N·m (221 lb ft)	310 N·m (229 lb ft)	250 N·m (184 lb ft)
Heavy (S)	30 mm	G 1 1/4 A	470 N·m (347 lb ft)	450 N·m (332 lb ft)	500 N·m (369 lb ft)
Heavy (S)	38 mm	G 1 1/2 A	560 N·m (413 lb ft)	540 N·m (398 lb ft)	600 N·m (443 lb ft)